

Monitoring Cisco ACI

Cisco: ACI PowerPack version 107

Table of Contents

Introduction	. 1
Supported Versions	2
Cisco ACI PowerPacks	2
Content in the Cisco ACI PowerPacks	2
Cisco: ACI	2
Cisco: ACI Dashboards	. 3
Cisco: ACI Reports	
What Does the Cisco: ACI PowerPack Monitor?	. 3
Installing the Cisco ACI PowerPacks	4
Discovering a Cisco ACI System	6
Prerequisites for Monitoring Cisco ACI	
Configuring a Credential for the Cisco ACI System	. 6
Discovering a Cisco ACI System	7
Viewing Information About the ACI System	. 10
Cisco ACI Dashboards	.12
ACI Application Dashboard	
ACI Health Dashboard	.14
ACI Leaf Health Dashboard	
ACI Overview Dashboard	.16
ACI Spine Health Dashboard	17
ACI Switch Dashboard	.18
ACI Switch Interface Dashboard	.20
ACI Tenant Health Dashboard	.21

Chapter

Introduction

Overview

This manual describes how to monitor a Cisco Application Centric Infrastructure system (ACI) in SL1 using the *Cisco: ACI* PowerPack.

The following sections provide an overview of Cisco ACI systems and the Cisco: ACI PowerPack:

Supported Versions	2
Cisco ACI PowerPacks	. 2
Content in the Cisco ACI PowerPacks	2
Cisco: ACI	2
Cisco: ACI Dashboards	. 3
Cisco: ACI Reports	. 3
What Does the Cisco: ACI PowerPack Monitor?	3
Installing the Cisco ACI PowerPacks	4

NOTE: ScienceLogic provides this documentation for the convenience of ScienceLogic customers. Some of the configuration information contained herein pertains to third-party vendor software that is subject to change without notice to ScienceLogic. ScienceLogic makes every attempt to maintain accurate technical information and cannot be held responsible for defects or changes in third-party vendor software. There is no written or implied guarantee that information contained herein will work for all third-party variants. See the End User License Agreement (EULA) for more information.

Supported Versions

The Cisco: ACI PowerPack can be used to monitor versions of Cisco ACI 1.0 (3f) and later.

Cisco ACI PowerPacks

To monitor a Cisco Application Centric Infrastructure (ACI) system using SL1, you must install the following PowerPack:

• Cisco: ACI

The following optional PowerPacks provide dashboards and reports for ACI:

- Cisco: ACI Dashboards
- Cisco: ACI Reports

Content in the Cisco ACI PowerPacks

Cisco: ACI

The Cisco: ACI PowerPack allows you to discover, model, and collect data from a Cisco ACI system. The Cisco: ACI PowerPack includes:

- An example credential you can use to create credentials to connect to the Cisco ACI system
- Dynamic Applications that discover and monitor the Cisco ACI system
- Run Book Automation Policies and Action Policies that create device records for ACI tenants and that convert a physical device to a virtual device with the same IP address and aligned Dynamic Applications
- Events for alert conditions in the Cisco ACI system
- Device Classes and Device Categories for each type of device in the Cisco ACI system
- Device dashboards for each type of discovered device

NOTE: The Run Book Actions included in the Cisco: ACI PowerPack can authenticate API requests using SHA256 hashing when running Federal Information Processing Standard (FIPS)-compliant installations of SL1 version 8.4.2 and later. The actions also support OpenSSL MD5 hashing for non-FIPS-compliant installations. For more information about authenticating API requests, see the **Using the ScienceLogic API** manual.

Cisco: ACI Dashboards

The Cisco: ACI Dashboards PowerPack includes pre-defined and configured dashboards that allow you to view data collected from Cisco ACI systems.

Cisco: ACI Reports

The Cisco: ACI Reports PowerPack includes reports that allow you to view data collected from Cisco ACI systems.

What Does the Cisco: ACI PowerPack Monitor?

- SL1 discovers and monitors the following Cisco ACI components:
 - Clusters of hardware-based servers that host the APIC. This is the hardware that hosts the APIC (Application Policy Infrastructure Controllers). An APIC manages the physical and virtual infrastructure of ACI. This hwardware cluster has an IP address. Initially, SL1 uses this IP address to discover the ACI system. SL1 displays each cluster as a component device with an IP address.
 - Application Policy Infrastructure Controllers (APICs). These are virtual machines that run on a cluster of hardware-based hosts. Each APIC is the unified point of automation, management, monitoring, and programmability for the ACI system. APICs control the physical and virtual infrastructure of ACI. Among other tasks, each APIC:
 - Controls policies that define ACI deployment of applications
 - Controls policies that define all automation and management
 - Hosts the API for ACI
 - Monitors the health of each component of ACI

SL1 displays each APIC as a component device.

- Spine Switches (Nexus 9K-family switches). These are hardware-based, stateless switches. These switches are the spine switches of the ACI infrastructure and provide switching and load-balancing across leaf switches. SL1 displays each spine switch as a component device.
- Leaf Switches (Nexus 9K-family switches). These are hardware-based, stateless switches. These switches are the leaf switches of the ACI infrastructure and provide switching. All devices in the ACI network communicate via leaf switches. Traffic with the source and destination on the same leaf switch is handled locally; traffic with the source and destination on two different leaf switches travels through a spine switch. SL1 displays each leaf switch as a component device.
- **Fabric**. A fabric is an instance of an ACI network. A fabric includes an APIC, spine switches, and leaf switches. SL1 displays the fabric name as the prefix to each tenant.
- **Pods**. A pod is a virtual device that is a container for all the APICs, spine switches, leaf switches, and associated descendents in an ACI infrastructure. SL1 displays each pod as a component device.

- **Tenants**. A tenant is a container for policies. These policies control domain-based access within the ACI network. There are three tenants for each fabric in ACI: Common, infrastructure, and management.
 - The common tenant contains policies for resources that are used by all tenants, including firewalls, load balancers, intrusion detection, and Layer 4 to Layer 7 services.
 - The infrastructure tenant contains policies that control the fabric resources (like the fabric VXLAN) and also policies that deploy resources.
 - The management tenant contains policies that control operations of the fabric and communication with the virtual machine controllers. SL1 displays each tenant as a virtual device.

SL1 displays each tenant as a virtual device. The name of each tenant is fabric::tenant. For example, ACI Fabric 1::common.

- Endpoint Groups (EPGs). Endpoints are devices that are connected to the network directly or indirectly (e.g., servers, virtual machines, or network-attached storage). They have an address, a location, attributes (e.g., version or patch level), and can be physical or virtual. An endpoint group is a group of endpoints that have common policy requirements, such as security, virtual machine mobility (VMM), QoS, or Layer 4 to Layer 7 services. For example, an endpoint group could contain all the endpoints in an application's web tier. Rather than configure and manage endpoints individually, they are placed in an endpoint group and are managed as a group. SL1 displays each endpoint group as a component device.
- Application Network Profiles. An Application Network Profile is a container that holds:
 - Multiple endpoint groups that are logically related to one another
 - The connections between the EPGs
 - The policies that define the connections between EPGs

Application Network Profiles can be organized by:

- The application they provide, by the function they provide (e.g., "infrastructure")
- Their location in the data center structure (for example, "DMZ")
- Any organizing principle that is required by your ACI implementation

SL1 displays each Application Network Profile as a component device.

Installing the Cisco ACI PowerPacks

Before completing the steps in this manual, you must import and install the latest version of the Cisco: ACI PowerPack. Optionally, you can also install the Cisco: ACI Dashboards PowerPack and the Cisco: ACI Reports PowerPack. TIP: By default, installing a new version of a PowerPack overwrites all content in that PowerPack that has already been installed on the target system. You can use the Enable Selective PowerPack Field Protection setting in the Behavior Settings page (System > Settings > Behavior) to prevent new PowerPacks from overwriting local changes for some commonly customized fields. (For more information, see the System Administration manual.)

To download and install a PowerPack:

- 1. Download the PowerPack from the <u>ScienceLogic Customer Portal</u>.
- 2. Go to the **PowerPack Manager** page (System > Manage > PowerPacks).
- 3. In the **PowerPack Manager** page, click the **[Actions]** button, then select Import PowerPack.
- 4. The Import PowerPack dialog box appears:

Import PowerPack™		×
Browse for file	Browse Import	

- 5. Click the [Browse] button and navigate to the PowerPack file.
- 6. When the **PowerPack Installer** modal page appears, click the **[Install]** button to install the PowerPack.

NOTE: If you exit the **PowerPack Installer** modal page without installing the imported PowerPack, the imported PowerPack will not appear in the **PowerPack Manager** page. However, the imported PowerPack will appear in the **Imported PowerPacks** modal page. This page appears when you click the **[Actions]** menu and select *Install PowerPack*.

Chapter

Discovering a Cisco ACI System

Overview

The following sections describe how to configure and discover Cisco Application Centric Infrastructure (ACI) component devices for monitoring by SL1 using the Cisco: ACI PowerPack:

Prerequisites for Monitoring Cisco ACI	. 6
Configuring a Credential for the Cisco ACI System	. 6
Discovering a Cisco ACI System	. 7
Viewing Information About the ACI System	10

Prerequisites for Monitoring Cisco ACI

To configure the SL1 system to monitor a Cisco ACI system using the Cisco: ACI PowerPack, you must first:

- Know the credentials (username and password) for a user account that has access to the API for the Cisco ACI system. The user account must have read-all access.
- Ensure that the APIC in your ACI system supports TLS 1.1 or TLS 1.2. SL1 does not support TLS 1.0.

Configuring a Credential for the Cisco ACI System

The Cisco: ACI PowerPack includes an example credential (Cisco: ACI Sample Credential 1) that you can use to create a credential for discovering your Cisco ACI system. This sample credential includes a single IP address in the **Hostname/IP** field.

To configure a credential for Cisco ACI, perform the following steps:

- 1. Go to the **Credential Management** page (System > Manage > Credentials).
- 2. Click the wrench icon (*for Cisco: ACI Sample Credential 1*. The **Credential Editor** page appears:

Credential Editor [24]			×
Edit Basic/Snippet Credential #24		New	Reset
Basic Settings			
	Credential Name		
Cisco: ACI Sample Credential 1			
Hostname/IP	Port	Timeout(ms)	
%D	443	30000	
	name	Password	
admin] [
	Save Save As		
L			


- 3. Supply values in the following fields:
 - Credential Name. Type a new name for the credential.
 - Hostname/IP. Enter "%D". You can enter the IP address of the cluster where the APIC resides, but this is not recommended.
 - Username. Type the username for a user account that has read-all access to the APIC API.
 - **Password**. Type the password for the username you entered in the **Username** field.
- 4. Click the [Save As] button.

Discovering a Cisco ACI System

To discover a Cisco ACI system, perform the following steps:

1. Go to the **Discovery Control Panel** page (System > Manage > Discovery).

2. Click the [Create] button. The Discovery Session Editor page appears:




- 3. Supply values in the following fields:
 - IP Address Discovery List. Enter the IP address of one of the servers in the cluster where the APIC resides.
 - Other Credentials. Select the credential you created for the Cisco ACI system.
 - Discover Non-SNMP. Select this checkbox.
- 4. Optionally, supply values in the other fields in this page. For a description of the fields in this page, see the **Discovery & Credentials** manual.
- 5. Click the **[Save]** button.
- 6. The **Discovery Control Panel** page will refresh. Click the lightning bolt icon (*F*) for the discovery session you just created.
- 7. In the pop-up window that appears, click the **[OK]** button. The page displays the progress of the discovery session.

NOTE: If your discovery session causes an HTTP 403 error, edit the credential so that the **Hostname/IP** field contains **only a single IP address** and then re-try discovery.

The initial discovery of a Cisco ACI system will align most Dynamic Applications; however, you will need to manually align the "Cisco: ACI IC UpTime" Dynamic Application for the internal collections data to be displayed on the **Device Properties** page (Registry > Devices > wrench icon).

To manually align the "Cisco: ACI IC UpTime" Dynamic Application:

- 1. From the **Device Properties** page for the Cisco ACI system, click the **[Collections]** tab. The **Dynamic Application Collections** page appears.
- 2. In the **Dynamic Application Collections** page, click the **[Action]** button and then select Add Dynamic Application from the menu. The **Dynamic Application Alignment** page appears.
- 3. In the **Dynamic Applications** field, select Cisco: ACI IC UpTime.



- 4. In the Credentials field, select the credential you created for the Cisco ACI system.
- 5. Click the [Save] button.
- 6. After aligning the Dynamic Application, click the **[Reset]** button and then click the plus icon (+) for the

Dynamic Application. If collection for the Dynamic Application was successful, the graph icons (4111) for the Dynamic Application are enabled.

Viewing Information About the ACI System

When SL1 performs collection for the ACI cluster, SL1 will create component devices for the components associated with the ACI system and align other Dynamic Applications to those component devices. Some of the Dynamic Applications aligned to the component devices will also be used to create additional component devices.

You can view all the devices, virtual devices, and component devices in the Cisco ACI system in the following places in the user interface:

 All devices, virtual devices, and component devices appear in the Device Manager page (Registry > Devices > Device Manager).

Image: Section	Device Name •	IP Address	Device Category	Device Class Sub-class	DID	Organization	Current State	Collection Group	Collection State	SNMP Credential	SNMP Version	
All ± Baold P Network Application (Soci Systems (AC) APC Centreller 7 System Notice 0 -				[
All ± Baold P Network Application (Soci Systems (AC) APC Centreller 7 System Notice 0 -	apic1	♥ 198.18.133.200	Network.Utility	Cisco Systems ACI	1	System	Notice 👃	CUG1	Active	-	- (1)	S 🗞 🛅
dialization ♥ - Network Application Coro Systems (ACI APC Controller 6 System Network _ AD CUC1 Active - - +00 (D is C) milliple.text1 Ø - Network Last Disco Systems (Neurol Lead) 0 System Mappr _ Disco Systems (Neurol Lead) CUC1 Active - - +00 (D is C) +00 (D is C) Active - - +00 (D is C) Active - - +00 (D is C) +00 (D is C) +00 (D is C) + - +00 (D is C) + + +00 (D is C) + + + + +	·// 보 보 apic1	- U	Network Application	Cisco Systems ACI APIC Controller	7	System	Notice 📣	CUG1	Active			i 🗞 🔟
	前 年 年 apic2		Network.Application	Cisco Systems ACI APIC Controller	4	System	Critical 🔺	CUG1	Active	-	- 😸	S 🗞 🔢
dig j Lead ■ Network Leaf S System Network _ 0 O(G) Adve - - + </td <td>📶 🚊 🚊 apic3</td> <td></td> <td>Network Application</td> <td>Cisco Systems ACI APIC Controller</td> <td>6</td> <td>System</td> <td>Notice 🔺</td> <td>CUG1</td> <td>Active</td> <td>-</td> <td>- 0</td> <td>5 🗞 🛅</td>	📶 🚊 🚊 apic3		Network Application	Cisco Systems ACI APIC Controller	6	System	Notice 🔺	CUG1	Active	-	- 0	5 🗞 🛅
11 <u>↓ 10051</u> 1 Units 1 Ulait Units 0 so Systems ACI Pod 2 System 1 Notice 1 ULait Adve	/// 夫夫Leaf1		Network.Leaf	Cisco Systems Nexus Leaf	3	System	Major 🛆	CUG1	Active	-	- 😸	ڬ 🗞 📊 👘
🕂 🕂 Spref – Network Spine Cisco Systems Nexus N9K-C9508 9 System Major 🖞 CUG1 Adve – – 🖷 🕃 🏷 🗽	📶 🚊 🚊 Leaf2		Network.Leaf	Cisco Systems Nexus Leaf	5	System	Notice 🔺	CUG1	Active	-		🕽 🗞 🔟
📶 🚊 😓 System 🔰 – Network Spine Claco Systems Nexus N9K-C9508 9 System Major 🛆 CUG1 Active – – – 🖶 🛱 🕸 🛅	// 글 글 pod-1		Network.Utility	Cisco Systems ACI Pod	2	System	Notice 🔺	CUG1	Active	-	- 😸	ڬ 🗞 📊
system Notice 🗗 CUG1 Active 🕪 25 🗞 🔝	小ALA Spine1		Network.Spine	Cisco Systems Nexus N9K-C9508	9	System	Major 🗥	CUG1	Active	-		🕽 🗞 🔢
	M 1 2 Spine2		Network.Spine	Cisco Systems Nexus N9K-C9508	8	System	Notice 🔺	CUG1	Active		- (1)	S 🗞 🛅

• The **Device Components** page (Registry > Devices > Device Components) displays a list of all root devices and component devices discovered by SL1 in an indented view, so you can easily view the hierarchy and relationships between child devices, parent devices, and root devices. To view the component devices associated with Cisco ACI, find the Cisco ACI root device and click its plus icon (+):

Data Descriptions* PLADDrag Color Data Did Descriptions* Data Dots Adverse PALAD Facint Common PALAD Facint Common Pale AD Facint Control		Collection	Collection		Current					Device					
Device Hame - Parties (2) Device Class 1 Sub-class (2) Device Class 1 Sub-class (2) <th>State</th> <th></th> <th>Group</th> <th></th> <th>State</th> <th>Organization</th> <th>Sustam</th> <th>DID</th> <th>Device Class Sub-class</th> <th>Category</th> <th>IP Address</th> <th></th> <th>Device Name +</th> <th></th> <th>0</th>	State		Group		State	Organization	Sustam	DID	Device Class Sub-class	Category	IP Address		Device Name +		0
$ \begin{array}{ $			Collection				Ojotein		Ciaco Ofaterra (Acriterrant				common	A CI Pablic L. Com	0
Pack/C Facinit: with a main of the structure Colsc Optimes (ACI feature) 10 Optime Colsc Optimes (ACI feature) Active Device Stams - IP Address Category Device Class State (Aciegory) Dial Optimes (Class Class	State	State	Group		State	Organization				Category					
Device Hame • Parks Parks Device Class I Sub-class Called on Device Class I Sub-class Do Crasmitter Fail Called on Fail Called on Device Class I Sub-class Do Crasmitter Fail Called on Fail	0.0														
Detec Islam PLAGess Catalog Catalog Data Group East	e 2						System	10	Cisco Systems ACI Tenant				infra	ACI Fabric1::infra	9
1. + journame Partner Presidences Partner Par	<u>Collection</u>	Collection State	Collection	<u>c</u>	Current State	Organization		סוס	Device Class I Sub-class	Device	IP Address		Device Name -		
Decks Name + Decks of State Decks Of State Decks Of State Decks Of State Calledon			20.000			21221122121	System							Affaccess	1. 2
Decks Name - PAddress Decks Object Name - Decks Object Name - Called on the part of	(e) 2	Active		CUG1	() Minor		System	1	Cisco Systems I ACI	Utility	133.200			apic cluster	0
I Mage: Dott Disc Name - Ulty Disc System AC Pod 2 System Index Cloth Unamable Detec Name - Pddess of Category Detec Name - Category Category State Category Unavailable 2 A state State O and Category Cate	Collection	Collection	Collection	0	Current		-,					9		and opic claster	
Descention Descention Descention Descention Calification Collection Calification	State	State	Group		State	Organization									
Detack Name + Easterny Category Detack State Decase Listerny Decase Listerny State Decase Listerny Decase							System	2			-			P mpod-1	1
2. An spic2 ♥ Application Cisco Systems JACAPC Controller 4 System Application Unavailable 3. Jin spic2 ♥ Application Cisco Systems JACAPC Controller 6 System Application Unavailable 3. Jin spic2 ♥ Lati Cisco Systems JACAPC Controller 6 System Application Unavailable 4 System Variance 3 System Titlager Cisco Systems JACAPC Controller 3 System Titlager Cisco Systems JACAPC Controller 3 System Titlager Cisco Systems JACAPC Controller 3 System Application Unavailable 5 System Variance ♥ Lati Cisco Systems JACAPC Controller 5 System Application Unavailable 6 Arritical ♥ Lati Cisco Systems JACAPC Controller 5 System Application Unavailable 7 Arritical ♥ Lati Cisco Systems JACAPC Controller 9 System Application Unavailable			Group	<u>u</u>	State	Organization	2	DI	pry Device Class Sub-class	Catego	IP Address		Device Name -		
Arritania Team Application Cisco Systems (ACMAPIC Controller 6 System Arteaum Cutot Unavailable 4 Arritania Team Leaf Cisco Systems (ACMAPIC Controller 5 System Magor Cutot Unavailable 5 Arritania Team Leaf Cisco Systems (Nexus Leaf 3 System Magor Cutot Unavailable 5 Arritania Team Leaf Cisco Systems (Nexus Leaf 5 System Magor Cutot Unavailable 6 Arritania Team Size Systems (Nexus Leaf 5 System Magor Cutot Unavailable		Unavailable		CUG1	A Health		System	7	Cisco Systems ACI APIC Controller	Application			ipic1		
A Description ♥															
Put Lan2 Image: Class Systems News Leaf System Image: Class Systems News Leaf System Image: Notable Util Unavailable 6. Systems News News News News News News News News															
6. 😕 📲 Spine 1 🔮 Spine Clisco Systems News N9K-C9508 9 System 1 11 Unavailable															
 Projemić w - domi jitelo travcico s osteni jitelo travcico s osteni jitelo travcico s 															

The Device Component Map page (Views > Device Maps > Components) allows you to view devices by root node and view the relationships between root nodes, parent components, and child components in a map. This makes it easy to visualize and manage root nodes and their components. SL1 automatically updates the Component Map as new component devices are discovered. The platform also updates each map with the latest status and event information. To view the map for Cisco ACI devices, go to the Component Map page and select the map from the list in the left NavBar. To learn more about the Component Map page, see the Views manual.

inbox Dashboa	ds Vie	ws			6
▼ Device Maps		mponent Map	Kiosk	Reset Guid	le l
Device Groups					_
Organizational	Zoom:	A			<u> </u>
 Categories Components 					
 Components apic cluster 		Trace File Screenhot			-1
ACI Fabric1::infra					
ACI Fabric1::common					
Topology Maps					
My Customized Maps					
 Shared Customized Maps Other Views 					
Other Views Classic Views	Fit Center				
	Edit: Nodes				
	Links				
	Shapes Text				
	Images				
	Save				
	Revert				
	Layers:	all a			
	Vodes	Pad			
	 state 				
	O Type ☑ Shapes				
	Text				
	Images				
		10/11 2 10/11 2 10/11 2 10/11 2 10/11 2 10/11 2 10/11 2 10/11 2			
Find Copyright © 2003 - 2015 Science	al onic Inc. All I	initia received			

Chapter

Cisco ACI Dashboards

Overview

The Cisco: ACI PowerPack comes paired with the Cisco: ACI Dashboards PowerPack. The Cisco: ACI Dashboards PowerPack contains dashboards that present data related to different aspects of a Cisco ACI system.

The following sections describe each of these dashboards:

ACI Application Dashboard	12
ACI Health Dashboard	14
ACI Leaf Health Dashboard	
ACI Overview Dashboard	
ACI Spine Health Dashboard	
ACI Switch Dashboard	
ACI Switch Interface Dashboard	
ACI Tenant Health Dashboard	

ACI Application Dashboard

The ACI Application Dashboard provides an overview of a selected Application Network Profile running on a Cisco ACI system.

In box Dashboards Views I Events	_ickets Knowledge Reports Registry	u l Puolem	Preferences Network Control NetFlow-A NetFlow-B NetFlow-C google-http://google-https
Dashboards	Dickets Knowledge Reports Registry	y gystern	Preferences Network Config NetFlow-A NetFlow-B NetFlow-C google-http google-https Actions Reset Guide
[Shared: ACI Application Dashboard] New			Actions reset Guide Pause Refresh
			Organizations Selector • Ø Device Selector •
S 1H 2H 4H 6H 12H	H 24H 3D 7D 14D 30D	00e (No Organizations Selected
	Application Health Score -	Application Healt	
default	100%	30 50 80	Critical Fault Major Fault Minor Fault Warning Fault Critical Fault Major Fault Warning Fault Device Domain Domain Domain Domain Domain Domain
LeoSimpleApp		30	70 @operational 0 0 0 0 @external 0 0 0
LeoTestwithL4L7Services	50%	20	80 □ communications 0 0 0 0 0 □ framework 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
P the second		10 2	90- 90- 90- 90- 90- 90- 90- 90- 90- 90-
	0% 12 Jun 14 Jun 16 Jun 18 Jun 20 Jun 22 Jun	100×	management 0 0 0
	- LeoSimpleApp: Cisco: ACI Health Score	TOOX	
Endpoint Groups Health Score (Bottom 5)		\sim	Virtual Machine CPU Usage (Top 5)
			Virtual Machine CPU Usage (100 5)
LecEPG			Linux-01; overall
SecondEPG			Unux-02: overall
0 % 10 % 20 % 30 % 40 Virtual Machine CPU Usage (Top 5)	 50 % 60 % 70 % 80 % 90 % Virtual Machine Memory Usage (Top 5) 		0 % 0.25% 0.5% 0.75% 1 % 1.3% 1.5% 1.8% 2 % 2.3% 2.5% 2.8% 3 % 3.3% 3.5% 3.8% 4 % 4.3% 4.5% 4.8% Virtual Machine Network Usage (Top 5) - Virtual Machine Disk Usage (Top 5)
nition internite of the suger (100-07-	· moundatine memory orange (100.5)		150.00 KB/sec
100.00 Mhz	Linux-01		750.00 KB/sec
			100.00 KB/sec
			500.00 KB/sec
50.00 Mhz			50.00 KB/sec
5 51	Linux-02		30.00 KB/sec
0-501			
0.00 Mhz 5 5	0 % 2 % 4 % 6 % 8 % 10 %	6 12 % 14 %	0.00 KB/sec
opyright © 2003 - 2015 ScienceLogic, Inc. All rights reserved.			

The ACI Application Dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **SELECT AN APPLICATION**. This widget allows the user to select an Application Network Profile running on the Cisco ACI system (from a list of applications) to display in the dashboard.
- Application Health Score (graph). This widget displays a line graph that depicts the average Health Score for the selected Application Network Profile over time.
- Application Health Score (gauge). This widget displays a gauge that depicts the average Health Score for the selected application. The gauge is updated every five minutes.
- Tenant Fault Counts by Type. This widget displays the 10 tenants with the most faults, by fault type. The table displays a row for each type and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Tenant Fault Counts by Domain. This widget displays the 10 tenants with the most faults, by fault domain. The table displays a row for each domain and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Endpoint Groups Health Score (Bottom 5). This widget displays a bar graph that depicts the five Endpoint Groups with the lowest ACI Health Score. Each bar represents an Endpoint Group and displays the average health score in percent.
- Virtual Machine CPU Usage (Top 5) (percent). This widget displays a bar graph that depicts the five VMWare virtual machines (that host EPGs) with the highest average CPU usage. Each bar represents a virtual machine and displays the average CPU usage in percent.
- Virtual Machine CPU Usage (Top 5) (mHz). This widget displays a bar graph that depicts the five VMWare virtual machines (that host EPGs) with the highest average CPU usage. Each bar represents a virtual machine and displays the average CPU usage in mHz.
- Virtual Machine Memory Usage (Top 5). This widget displays a bar graph that depicts the five VMWare virtual machines (that host EPGs) with the highest average memory usage. Each bar represents a virtual machine and displays the average memory usage in percent.

- Virtual Machine Network Usage (Top 5). This widget displays a bar graph that depicts the five VMWare virtual machines (that host EPGs) with the highest average network usage. Each bar represents a virtual machine and displays the average network usage in KB/second.
- Virtual Machine Disk Usage (Top 5). This widget displays a bar graph that depicts the five VMWare virtual machines (that host EPGs) with the highest average disk usage. Each bar represents a virtual machine and displays the average disk usage in KB/second.

ACI Health Dashboard

The ACI Health dashboard provides an overview of the health of the ACI system.



The ACI Health dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- **Device Selector**. This widget allows the user to specify the device(s) to include in the dashboard. If the user selects one or more values in the Organization Selector widget, only devices from the selected organization (s) appear in the Device Selector.
- **Pod Health Score**. This widget displays a gauge that depicts the average Health Score for the full system under an ACI pod. The gauge is updated every five minutes.
- Switch Utilization (Average interface Utilization). This widget displays a bar graph that depicts the 10 switches with the highest average interface utilization. Each bar represents a switch (spine or leaf) and displays the average interface usage in percent.
- **Pod Health Score**. This widget displays a line graph that depicts the average Health Score for the full system under an ACI pod. The graph displays health in percent over time.

- APIC CPU Utilization. This widget displays a line graph that depicts the average CPU usage for each APIC in the ACI system. The graph displays a line for each APIC. Each line displays average CPU usage in percent over time.
- Number of Authentications. This widget displays a line graph that depicts the number of successful authentications to the cluster that hosts the APIC(s). The line graph displays the number of successful authentications over time.
- Fault Counts by Type. This widget displays a line graph that depicts the type of faults that have occurred on the cluster that hosts the APIC(s). The graph displays a line for each fault severity (critical faults, major faults, minor faults, and warning faults). Each line displays the number of faults over time.
- APIC Memory Utilization. This widget displays a line graph that depicts the average memory usage for each APIC in the ACI system. The graph displays a line for each APIC. Each line displays average memory usage in percent over time.
- Fabric Switch Health Scores (Bottom 10). This widget displays a bar graph that depicts the 10 switches (both spines and leaf) with the lowest health scores. Each bar represents a switch and displays health in percent.
- Tenant Health Score (Bottom 10). This widget displays a bar graph that depicts the 10 tenants with the lowest health scores. Each bar represents a tenant and displays health in percent.
- Fault Counts by Type. This widget displays the 10 devices with the most faults, by fault type. The table displays a row for each type and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Fault Counts by Domain. This widget displays the 10 devices with the most faults, by fault domain. The table displays a row for each domain and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.

ACI Leaf Health Dashboard

The ACI Leaf Health dashboard provides an overview of the health of each leaf and its components.




The ACI Leaf Health dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- Leaf Switch Health Score. This widget displays a line graph that depicts the Health Score for each leaf in the ACI system. The graph displays a line for each leaf switch. Each line displays health in percent over time.
- Fabric Card Health Score (Bottom 5). This widget displays a bar graph that depicts the five fabric cards (among all the leaf switches) with the lowest health scores. Each bar represents a fabric card and displays health in percent.
- Supervisor Card Health Score (Bottom 5). This widget displays a bar graph that depicts the five supervisor cards (among all the leaf switches) with the lowest health scores. Each bar represents a supervisor card and displays health in percent.
- Fan Tray Health Score (Bottom 5). This widget displays a bar graph that depicts the five fan trays (among all the leaf switches) with the lowest health scores. Each bar represents a fan tray and displays health in percent.
- **Power Supply Health Score (Bottom 5)**. This widget displays a bar graph that depicts the five power supplies (among all the leaf switches) with the lowest health scores. Each bar represents a power supply and displays health in percent.
- Interface Health Score (Bottom 10). This widget displays a bar graph that depicts the 10 interfaces (among all the leaf switches) with the lowest health scores. Each bar represents an interface and displays health in percent.

ACI Overview Dashboard

The ACI Overview dashboard provides an overview of the status of the entire ACI system.



The ACI Health dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- **Device Selector**. This widget allows the user to specify the device(s) to include in the dashboard. If the user selects one or more values in the Organization Selector widget, only devices from the selected organization (s) appear in the Device Selector.
- **Pod Health Score**. This widget displays a gauge that depicts the average Health Score for the full system under an ACI pod. The gauge is updated every five minutes.
- Switch Utilization (Average interface Utilization). This widget displays a bar graph that depicts the 10 switches with the highest average interface utilization. Each bar represents a switch (spine or leaf) and displays the average interface usage in percent.
- Monitored Component Count. This widget displays a line graph that depicts the number of monitored components in the ACI system. The graph displays number of components over time.
- **Tenant Health Score (Bottom 5)**. This widget displays a bar graph that depicts the five tenants with the lowest health scores. Each bar represents a tenant and displays health in percent.
- Endpoint Group Health Score (Bottom 5). This widget displays a bar graph that depicts the five endpoint groups with the lowest health scores. Each bar represents an endpoint group and displays health in percent.
- Fabric Switch Health Scores (Bottom 5). This widget displays a bar graph that depicts the five switches (both spines and leaf) with the lowest health scores. Each bar represents a switch and displays health in percent.
- APIC CPU Utilization. This widget displays a line graph that depicts the average CPU usage for each APIC in the ACI system. The graphs displays a line for each APIC. Each line displays average CPU usage in percent over time.
- Critical Fault Count. This widget displays a bar graph that depicts each part of the ACI system where a critical fault occurred. Each bar represents a component of the ACI system where a critical fault occurred and displays the number of critical faults.
- Major Fault Count. This widget displays a bar graph that depicts each part of the ACI system where a major fault occurred. Each bar represents a component of the ACI system where a major fault occurred and displays the number of major faults.
- *Minor Fault Count*. This widget displays a bar graph that depicts each part of the ACI system where a minor fault occurred. Each bar represents a component of the ACI system where a minor fault occurred and displays the number of minor faults.
- Warning Fault Count. This widget displays a bar graph that depicts each part of the ACI system where a warning fault occurred. Each bar represents a component of the ACI system where a warning fault occurred and displays the number of warning faults.
- **Event Kiosk**. This widget displays a list of all events associated with the ACI system. The interface is the same as that of the Events Console.

ACI Spine Health Dashboard

The ACI Spine Health dashboard provides an overview of the health of each spine and its components.

IShboards (hared: ACI Spine Health Dashboard)		 New 									Ac	tions Re Pai	use Refr
1H 2H	4H 6H	12H 2	4H 3D	70	14D 30D 9	OD	7 Organizations	Selected	<u>0r</u>	anizations Select	a •		
ne Switch Health					Line Card Health Score (Bottom 5)								
					topology/pod-1/node-202/sys/chilcsiot-1/lo								
%													
					topology/pod-1/node-201/sys/ch/lcsiol-1/lo	,							
18. Jun 19. J		21. Jun 22. Ju		24. Jun									
Tray Health Score (Bottom 5)	- Spine1: Health Sco	e (%)	-		Power Supply Health Score (Bottom 5)	0% 10%	20 %	30% 40%	6 50 %	60 %	70 %	80% 90	% 100 %
Ine 1: topologybod-1Imode 2016/systch18ich-11t Ine2: topologybod-1Imode 2020/systch18ich-11t Ine2: topologybod-1Imode 2021/systch18ich-11t Ine 1: topologybod-1Imode 2016/systch18ich-21t 0 % 20 5		Spine2: topologylpod-1/inode- 202/sysich/supsid-1/sup Spine1: topologylpod-1/inode- 201/sysich/supsid-1/sup	% 20% 40% €	0 % 80 % 100 %	Spine2: topology/pod-1/mode-202/systchip Spine1: topology/pod-1/mode-201/systchip Spine2: topology/pod-1/mode-202/systchip Spine1: topology/pod-1/mode-201/systchip	osusiol-1/psu	10% 2	0% 30%	40 %	50 % 60 %	70 %	80% 6	90 % 100
ric Interfaces Health Score (Bottom 10)													
	Spine 1: topology/pod-1/hode-2 Spine 2: topology/pod-1/hode-2 Spine 2: topology/pod-1/hode-2 Spine 1: topology/pod-1/hode-2 Spine 1: topology/pod-1/hode-2	02/sys/tunnel-(tunnel/) 02/sys/tunnel-(tunnel4) 01/sys/tunnel-(tunnel1)											
ine1: topologylpod-1/node-201/sys/lpv4	Instidom-management/If-(mgmt0)/a	ddr-(173.36.219.51/24)							_				
	Spine1: topology/pod-1/node-2					_	_	_		_			
	Spine2: topology/pod-1/node-2					_	-						
Spine1: topology	pod-1/node-201/sys/ipv4/inst/dom-n	anagemenutr-(mgmt0]					_						

The ACI Spine Health dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- Spine Switch Health Score. This widget displays a line graph that depicts the Health Score for each spine in the ACI system. The graph displays a line for each spine switch. Each line displays health in percent over time.
- Line Card Health Score (Bottom 5). This widget displays a bar graph that depicts the five line cards (among all the spine switches) with the lowest health scores. Each bar represents a line card and displays health in percent.
- Fan Tray Health Score (Bottom 5). This widget displays a bar graph that depicts the five fan trays (among all the spine switches) with the lowest health scores. Each bar represents a fan tray and displays health in percent.
- Supervisor Card Health Score (Bottom 5). This widget displays a bar graph that depicts the five supervisor cards (among all the spine switches) with the lowest health scores. Each bar represents a supervisor card and displays health in percent.
- **Power Supply Health Score (Bottom 5)**. This widget displays a bar graph that depicts the five power supplies (among all the spine switches) with the lowest health scores. Each bar represents a power supply and displays health in percent.
- Interface Health Score (Bottom 10). This widget displays a bar graph that depicts the 10 interfaces (among all the spine switches) with the lowest health scores. Each bar represents an interface and displays health in percent.

ACI Switch Dashboard

The ACI Switch dashboard provides an overview of the health of all the switches (spine and leaf) in the ACI system.

Inbox Dashboards Views	Events ickets K_nowledge Report	s <u>R</u> egistry <u>S</u> ystem	Preferences Network Config NetFlow-A 1	NetFlow-B NetFlow-C google-http	google-https
					Actions Reset Guide
[Shared: ACI Switch Dashboard]	New				Pause Refres
		Organizations Selector •	Device Selector -	Fault Counts By Domain	
1H 2H 4H 6H 12H 24H	3D 7D 14D 30D 90D 7 Organiz	ations Selected	1 Device Selected	Critical Fault Domain Device M	ajor Fault Domain Minor Fault Domain Domain
				Spine2: external 0	0 0
istom Device Table	Spine2: Health Score (Last 7 days)	Fault Counts By Type		Spine2: infra 0 Spine2: access 0	0 0
Device Name	20 50 50	Device		Spine2: management 0	6 0
MSpine2	30 70	Spine2: communications		Spine2: security 0	0 0
MSpine2	20 80	Spine2: environmental Spine2: config	0 0 0 0	Spine2: tenant 0	0 0
Spine1		Spine2: operational	0 0 2 7	Spine2: framework 0	0 0
PartLeaf2					
	¥ 98×				
witch Total Fault Counts			Number of Faults		
pine2: Warning			1.5Faults		
prilez, training					
Spine2: Major			1Faults		
			0.5Faults		
Spine2: Minor					
			OFaults		
Spine2: Critical			18. Jun 19. Jun		2. Jun 23. Jun 24. Jun
0.00 0.50 1.00 1.50 2.0	00 2.50 3.00 3.50 4.00 4.50 5.00	5.50 6.00 6.50 7.00		Spine2: Major (Faults)	
itical Fault Counts on Modules (Top 5)	 Major Fault Counts on Modules (Top 5 	5)	 Minor Fault Counts on Modules (Top 5) 	Total Warnings on Mod	ules (Top 5)
ptFan - node-202/sys/chittslot-1/tt/fan-	I1Physif - node-202/sys/phys-(eth1/2)	9]	eqptPsu - node-202/sys/ch/psusiot- 1/psu	I1Physif - node-202/s	ys/phys-[eth1/1]
peran - node-2025 yaronisi ob 1/totan- 1	I1Physlf - node-202/sys/phys-[eth1/	a)	I1Physif - node-202/sys/phys-[eth1/29]	I1Physlf - node-202/s	ys/phys-(eth 1/4)
	I1Physif - node-202/sys/phys-[eth1/1	0	11Phystf - node-202/sys/phys-[eth1/1]	I1Physlf - node-202/s	ys/phys-(eth 1/2)
ptFan - node-202/sys/chiltslot-2/lt/fan-	11Physlf - node-202/sys/phys-[eth1/2/	4	11Physlf - node-202/sys/phys-[eth1/11]	I1Physlf - node-202/s	ys/phys-(eth 1/7)
1	I1Physlf - node-202/sys/phys-(eth1/2)	2]	I1Physif - node-202/sys/phys-[eth 1/24]	I1Physlf - node-202/sy	s/phys-(eth1/29)

The ACI Switch dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- **Device Selector**. This widget allows the user to specify the device(s) to include in the dashboard. If the user selects one or more values in the Organization Selector widget, only devices from the selected organization (s) appear in the Device Selector.
- **Custom Device Table**. This widget displays a table that lists the spine switches and leaf switches in the ACI system. This widget allows the user to specify the switches to include in the dashboard.
- Health Score (Last 7 days). This widget displays a gauge that depicts the average Health Score for the previous seven days for the switch selected in the Custom Device Table widget. The gauge is updated every five minutes. You can view the health score for only one switch at a time.
- Fault Counts by Type. This widget displays a table that lists each switch and the type where faults occurred. The table displays a row for each switch/type and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Fault Counts by Domain. This widget displays a table that lists each switch and the domain where faults occurred. The table displays a row for each switch/domain and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Switch Total Fault Counts. This widget displays a bar graph that depicts each switch where a fault occurred, the severity of the fault, and the number of faults. Each bar represents a switch/fault severity and the number of times the fault occurred.
- [Number of Faults]. This widget displays a line graph that depicts the average CPU usage for each APIC in the ACI system. The graph displays a line for each switch. Each line displays the total number of faults over time.

- Critical Fault Count. This widget displays a bar graph that depicts the five components of a switch where the most critical faults occurred. Each bar represents a component of a switch where a critical fault occurred and displays the number of critical faults.
- Major Fault Count. This widget displays a bar graph that depicts the five components of a switch where the most major faults occurred. Each bar represents component of a switch where a major fault occurred and displays the number of major faults.
- Minor Fault Count. This widget displays a bar graph that depicts the five components of a switch where the most minor faults occurred. Each bar represents a component of a switch where a minor fault occurred and displays the number of minor faults.
- Warning Fault Count. This widget displays a bar graph that depicts the five components of a switch where the most warning faults occurred. Each bar represents component of a switch where a warning fault occurred and displays the number of warning faults.

ACI Switch Interface Dashboard

The ACI Switch Interface dashboard provides an overview of the status of the interfaces on all the switches (spine and leaf) in the ACI system.

Control Control Control Control Control 1 1 24 44 04 10 20 10 200 <td< th=""><th>nbox <u>Deshboards y</u>lews <u>Events Dickets Knowledge</u> Rep<u>orts Registry System Preference</u></th><th>es Network Conflig NetFlow-A NetFlow-B NetFlow-C google-http google-https </th></td<>	nbox <u>Deshboards y</u> lews <u>Events Dickets Knowledge</u> Rep <u>orts Registry System Preference</u>	es Network Conflig NetFlow-A NetFlow-B NetFlow-C google-http google-https
Name Description Description <thdescription< th=""> <thde< th=""><th>Dashboards</th><th></th></thde<></thdescription<>	Dashboards	
1 2/1 4/4 6/4 6/4 7/4 2/4 3/0 7/0 1/40 3/0 8/0 7/0 paradom Steletide 1/0	Shared: ACI Switch Interface Dashboard] View	mause Reliesi
Action Action action Comparison been Comparison been Comparison been Deline function De	S 11 21 41 81 191 241 20 70 140 200 800 97	
Deskt Stame Benet 1 besingsord hinde-200 Stame		ons Selected 4 Devices Selected
Link Spin-2 Spin-2 <th>Custom Device Table ACI Switch Utilization (Average Interface Utilization)</th> <th>Interface Health Score (Bottom 10)</th>	Custom Device Table ACI Switch Utilization (Average Interface Utilization)	Interface Health Score (Bottom 10)
Like Like Like Upsegges Holes-2003yrk Lines Holes Emerge Holes Emerg Holes Emerge Holes Emerge Hol		Spine2: topologypod-1/node-202/sys/tunnel-[tunnel7]
June And Description Description Description <thdescripti< td=""><td>Spine1: topology/pod-1/hode-201</td><td>Spine2: topology/pod-1/node-202/sys/tunnel-[tunnel4]</td></thdescripti<>	Spine1: topology/pod-1/hode-201	Spine2: topology/pod-1/node-202/sys/tunnel-[tunnel4]
July Bar2	Sellest1	
Automation Description	Spine2: topology/pod-1/mode-202	
Control Status Control Status Control Status Stat		Spine1: topolog/pod-1/node-201/sys/pv4/inst/dom-management/f-
Left boologies hubble 10 by hub	/AmtSpine2 Ceat2: topology/pod-1/node-102	(mgm0) Spine2: topology/pod-1/node-202/sys/humel-l/hume11
Number of the structure of the str		Lesf1: topology/pod-1/node-101/sys/tunnel-[tunnel12]
0 % 10 % 00 % 00 % 00 % 00 % 00 % 00 %	Leaf1: topology/pod-1/node-101	
bit Matched Value (Fit and Koll (Nige UD)		
hear-ode-2003pybyhy-(4h102] bit		
edf - rode - 1023ysphyselyeline 101 edf - rode - 1023ysphyseline 101 edf - rode - r		
iwise-ode-1003ysphyse_iething		
edf - rode - 100 systems - deft 100 - 100 systems - deft 100 - 100		
late: -dea-1032p3p3p4_e(4017) set: -dea-1032p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016) set: -dea-1042p3p4p4_e(4016)		
lab 0.05 0.01 0.015 0.04 0.05		
lab		
lab 0.054 0.054 0.054 0.054 0.054 0.054 0.054 0.054 0.054 0.054 0.055 0.054 0.055 0.054 0.055 0.054 0.055 0.054 0.055 0.054 0.055 0.054 0.055 0.054 0.055 0		
0 % 0 00 % 0 1 % 0 00 % 0 1 % 0 1 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 0 % 0 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % 0 % 0 % 0 % 1 % 2 % 1 % 4 % 5 % 0 % <td></td> <td></td>		
bp:0 Control VEX.NEWD Creptod 1bb::node-2003/pip/hpip/s1010 VEX.NEWD Creptod 1bb::node-2003/pip/hpip/s1010 VEX.NEWD Creptod 1bb::node-2003/pip/hpip/s1010 Defended Defended Defended Spinz: 2bit node-2003/pip/hpip/s1010 Defended Defended Defended Spinz:		
Lac2 Lac2 Lac2 Lac2 Lac2 Lac2 Lac2 Lac2		AFD WRED Drop Out fab - node-202/sys/phys-(eth1/2) (Packets), Buffer Drop Out fab - node-202/sys/phys-(eth1/2) (Packets), Errors Out fab - node-202/sys/phys-
Lead 2: 6	Leaf2 fab - node-102(sys)phys-[eth1/49]	
Latt 124 - node-1019/3249/4-681102 Latt 124 - node-1019/3249/4-681102 Latt 124 - node-1019/3249/4-681102 Bipe2 260 - node 2019/3249/4-681102 Bipe2 260 - no	Leaf2: fab - node-102/sys/phys-[eth1/50]	0.06Packets
Latit Latit - node - 1015ystoph-efit 101 Latit - node - 1015ystoph-efit 101 Spinol 2 har. code - 1015ystoph-efit 102 Spinol 2 har. code - 1015ystoph-efit	Spine2: fab - node-202/sys/phys-(eth 1/1)	
Lead2 lack - node-103typsphy-eht10 gene2 lack - node-103typsphy-eht10 gene2 lack - node-103typsphy-eht10 web1 lack - node-103typsphy-eht10 lack - 10x-node-103typsphy-eht10 men2 lack - 10x-node-100typsphy-eht10 men2 lack -	Leaf1: leaf - node-101/sys/phys-[eth1/1]	0.04Packets
Least Bar - node-101spsphr-jefn112 Least Bar - node-101spsphr-jefn122 Least Bar - node-101spsphr-jefn122 Least Bar - node-101spsphr-jefn122 Least Bar - node-101spsphr-jefn122 Decast Bar - node-101spsphr-jefn122	Leaf1: Jeaf - node-101/sys/phys-[eth1/24]	
Ladit für -node-Hollsysishing-Kehn FSG	Leat2: leaf - node-102/sys/phys-(eth 1/1)	0.02Packets
Ladit für -node-Hollsysishing-Kehn FSG	Spine2: fab - node-202/sysiphys-(eth 1/2)	
Left 1a- 0x49-193xp3/m444 w1	Leaf1; fab - node-101/sys/phys-jeft 1/50	0Packets 18 Jun 19 Jun 20 Jun 21 Jun 22 Jun 23 Jun 24 Jun
Spine2_rev_Vive_U Vive_U Vive_	Leaft fab - node-101/svs/bhvs-felth1/491	
	Scient: No - node-2019/synchroseteming	
0 00 0 0 0 0 15 0 20 0 25 0 30 0 35 0 40 0 45 0 50 0 55 0 80 0 85 0 70 0 75 0 80 0 85 0 100 105 100 105 100 105		

The ACI Switch Interface dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- **Device Selector**. This widget allows the user to specify the device(s) to include in the dashboard. If the user selects one or more values in the Organization Selector widget, only devices from the selected organization (s) appear in the Device Selector.

- **Custom Device Table**. This widget displays a table that lists the spine switches and leaf switches in the ACI system. This widget allows the user to specify the switches to include in the dashboard.
- ACI Switch Utilization (Average Interface Utilization). This widget displays a bar graph that displays the 10 switch interfaces with the highest utilization. Each bar represents an interface and displays utilization in percent.
- Interface Health Score (Bottom 10). This widget displays a bar graph that displays the 10 switch interfaces with the lowest health scores. Each bar represents an interface and displays health in percent.
- Host Interface Utilization (Max of TX and RX) (Top 10). This widget displays a bar graph that displays the 10 host-facing switch interfaces with the highest utilization. Each bar represents an interface and displays utilization in percent.
- Fabric Interface Utilization (Max of TX and RX) (Top 10). This widget displays a bar graph that displays the 10 fabric-facing switch interfaces with the highest utilization. Each bar represents an interface and displays utilization in percent.
- Top 10: Cisco: ACI Interface Performance Total Drops (Maximum, All devices, Last <timespan>). This widget displays a bar graph. The bar graph displays the 10 switch interfaces with the highest number of drops over the timespan. Each bar represents an interface and displays the total number of drops for the timespan.
- Interface Drops and Errors (Top 5). This widget displays a line graph that depicts drops and errors over time. The graph includes a line for each type of drop or error: SFD WRED Drop Out, Buffer Drop Out, Errors Out, Forward Drop In, Buffer Drop In, and Load Balancer Drop In. Each line displays the number of drops or errors over time.

ACI Tenant Health Dashboard

The ACI Tenant Health dashboard provides an overview of the status of a selected tenant in the ACI system.



The ACI Tenant Health dashboard displays the following widgets:

- Context Quick Selector. This widget allows the user to set the timespan for the dashboard.
- **Organization Selector**. This widget allows the user to specify the organization(s) to include in the dashboard.
- **Device Selector**. This widget allows the user to specify the device(s) to include in the dashboard. If the user selects one or more values in the Organization Selector widget, only devices from the selected organization (s) appear in the Device Selector.
- **SELECT A TENANT**. This widget displays a table that lists the tenants in the ACI system. This widget allows the user to specify the switches to include in the dashboard.
- **Tenant Health Score** (graph). This widget displays a line graph that depicts the average Health Score for one or more selected tenants over time. The graph includes a line for tenant. Each line displays health in percent over time.
- **Tenant Health Score** (gauge). This widget displays a gauge that depicts the average Health Score for one or more selected tenants. The gauge is updated every five minutes.
- Tenant Fault Counts by Type. This widget displays the 10 tenants with the most faults, by fault type. The table displays a row for each type and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- **Tenant Fault Counts by Domain**. This widget displays the 10 tenants with the most faults, by fault domain. The table displays a row for each domain and four columns, one for each fault severity: Critical faults, major faults, minor faults, and warning faults.
- Bridge Domain Health Score (Bottom 5). This widget displays a bar graph that depicts the five bridge domains with the lowest ACI Health Score. Each bar represents a bridge domain and displays the average health score in percent.
- **Private Network Health Score (Bottom 5)**. This widget displays a bar graph that depicts the five private networks with the lowest ACI Health Score. Each bar represents a private network and displays the average health score in percent.
- Application Health Score (Bottom 5). This widget displays a bar graph that depicts the five applications with the lowest ACI Health Score. Each bar represents an application and displays the average health score in percent.
- Endpoint Groups Health Score (Bottom 5). This widget displays a bar graph that depicts the five endpoint groups with the lowest ACI Health Score. Each bar represents an endpoint group and displays the average health score in percent.
- Top 10: Cisco: ACI Fault Counts Total Faults (Average, All devices, Last <timespan>). This widget displays a bar graph that depicts the ACI tenants with the highest number of total faults over the timespan. Each bar represents a tenant/fault severity and the number of times the fault occurred.

© 2003 - 2019, ScienceLogic, Inc.

All rights reserved.

LIMITATION OF LIABILITY AND GENERAL DISCLAIMER

ALL INFORMATION AVAILABLE IN THIS GUIDE IS PROVIDED "AS IS," WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED. SCIENCELOGIC [™] AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT.

Although ScienceLogic[™] has attempted to provide accurate information on this Site, information on this Site may contain inadvertent technical inaccuracies or typographical errors, and ScienceLogic[™] assumes no responsibility for the accuracy of the information. Information may be changed or updated without notice. ScienceLogic[™] may also make improvements and / or changes in the products or services described in this Site at any time without notice.

Copyrights and Trademarks

ScienceLogic, the ScienceLogic logo, and EM7 are trademarks of ScienceLogic, Inc. in the United States, other countries, or both.

Below is a list of trademarks and service marks that should be credited to ScienceLogic, Inc. The ® and ™ symbols reflect the trademark registration status in the U.S. Patent and Trademark Office and may not be appropriate for materials to be distributed outside the United States.

- ScienceLogic[™]
- EM7[™] and em7[™]
- Simplify IT™
- Dynamic Application™
- Relational Infrastructure Management[™]

The absence of a product or service name, slogan or logo from this list does not constitute a waiver of ScienceLogic's trademark or other intellectual property rights concerning that name, slogan, or logo.

Please note that laws concerning use of trademarks or product names vary by country. Always consult a local attorney for additional guidance.

Other

If any provision of this agreement shall be unlawful, void, or for any reason unenforceable, then that provision shall be deemed severable from this agreement and shall not affect the validity and enforceability of any remaining provisions. This is the entire agreement between the parties relating to the matters contained herein.

In the U.S. and other jurisdictions, trademark owners have a duty to police the use of their marks. Therefore, if you become aware of any improper use of ScienceLogic Trademarks, including infringement or counterfeiting by third parties, report them to Science Logic's legal department immediately. Report as much detail as possible about the misuse, including the name of the party, contact information, and copies or photographs of the potential misuse to: legal@sciencelogic.com



800-SCI-LOGIC (1-800-724-5644)

International: +1-703-354-1010